Lenovo Service Center - Lenovo Service Centers Contacts

Generated: 18 August, 2025, 02:42

My Ienovo X1 Yoga Touch Screen No Longer Working Posted by Ienovoadmin - 06 Jan 2017 11:28 Try ths, Updating all drivers for BIOS and other devices Disabling and re-enabling the touchscreen device and Wacom HID device in Device Manager Uninstalling touch screen device and Wacom HID Device in Device Manager Unchecking "allow computer to turn off this device to save power" Reboot from safe mode Restore Windows to factory default

1/