

## Laptop won't come out of sleep mode....HELP!!!!

Posted by lenovoadmin - 06 Jan 2017 12:38

---

Try this and see if it helps.

1. Go to and click the "Power Icon" and then click "More Power Options".
2. Under the plan that is currently selected (Balanced, Power Saver....) click "Change Plan Settings".
3. Now click "Change Advanced Power Settings".
4. On the next screen you may have to click at top of screen on "Change settings that are currently unavailable".
5. Open the "Sleep Setting" and find "Hybrid Sleep".
6. Change/set it to allow.
7. Click "OK".
8. Finally shut down and power up the computer.

=====